capetune.com

NEO-PACTO 4G AUTO-DIALIER PHONE SMS SETTINGS

IMPORTANT: **INSERT BATTERY OR PLUG THE PHONE TO ELECTIC POWER TO AUTO-POWER ON PHONE.**

Setting up the Auto Dial Number.
STEP 1: Insert a SIM card in "SIM Slot" at the back of the **Neo-Pacto** phone and insert battery to power up the phone.

STEP 2: Using your mobile phone, send this SMS Text message to the SIM card phone number in the **Neo-Pacto** Phone: **set***passcode***number** **Example: set*1111*07543025555** where **Passcode** is '**1111**' and **07543025555** is '**number'**, your Office phone number you want the **Neo-Pacto** phone to auto dial once the hand piece is picked up. **'Pick up handpiece and it should start auto-calling'**

NOTE: *All set words must be in "lower-case" letters*

Remote check the number of calls
This is to check how many calls that the phone has made.
Send the following SMS (Text Message) to the mobile phone number in the phone:
query*passcode
Example: Send the SMS in this order **query*1111** were **1111** is the passcode.
The phone will reply back your SMS (by SMS text message) to the mobile phone you sent the message from with the call details including outgoing and incoming calls with call durations and time and date stamps.

Changing PASSCODE:
To change **PASSCODE** of the **Neo-Pacto** remotely, send this SMS Text to the **Neo-Pacto**; **setpassword*1111*NewPassword** EG; **setpassword*1111*2222**. This will change **SMS PASSCODE** from **1111** to **2222**

Wall Mounting the Neo-Pacto Phone:
If you intend to wall-mount the phone on the wall horizontally, you will need to **stick** the provided **"self-adhesive foam"** on the **Battery cover** on the back of the **NEO-PACTO** phone to give the phone the right angle when wall-mounted.